



## PREMIUM AUTO DISH WASH DETERGENT

- Powerful removes stubborn soilage and tannin stains
- Economical in use
- Anti-corrosive protects your machine

## USES

A powerful detergent for machine dishwashing that removes stubborn soiling with ease.

RAPIER is a high quality, sophisticated product which ensures consistently excellent results in both soft and hard water areas. An anti-corrosive agent has been added to the formula to protect the dishwashing machine.

Ideal for washing cutlery, crockery, stainless steel and utensils. Suitable for all dish washing machines in food and catering establishments. Can be used as an effective detergent for tray washing machines.

Code: 303



## DIRECTIONS

Put dosing tube into the container of Rapier, so that it reaches the bottom. The dosing unit, which has been pre-set to a specific concentration, will automatically dispense RAPIER into the machine. To remove stubborn tannin, tea or coffee stains, soak crockery in a solution of 1 part RAPIER to 100 parts water for between 2 and 5 minutes, depending upon the degree of soiling.

N.B. DO NOT use on aluminium, zinc, magnesium and their alloys.





## **DILUTIONS**

RAPIER : WATER	
Machine washing	Tannin stain removal
2-8ml per litre	1:100

